

Installation Instructions For

Signs

Surface Mounted Signs

Ecoglo exit signs are to be installed only where there will be sufficient natural or artificial light to keep them charged whenever the building is occupied.

If unsure, contact Ecoglo

Ecoglo International Limited

Email: info@ecoglo.com

Ph: +64 3 348 3781

www.ecoglo.com



Signs Surface Mounted Signs

Mounting Location

- At doors: mount on a vertical surface within 600mm of the door where the sign is least likely to be obscured from view. Where the ceiling is directly above the top of the door, the sign can be mounted on the door as long as the door is outward opening, and has a self-closer mechanism.
- On walls: mount 2 - 2.5 metres above floor level, or where it is least likely to be obscured from view.
- When installing the sign make sure it is parallel to the nearest horizontal building feature, so that it looks level to the eye.



Mounting Surfaces

- Timber: screw install (use all 4 holes in the sign).
- Plasterboard: screw install with suitable anchors (use all 4 holes in the sign).
- Glass: adhere with suitable high strength white foam back mounting tape. For signs up to 420mm x 230mm apply two strips of tape 200mm x 25mm near the top and bottom of the sign.
- Concrete, Solid plaster, Steel: adhere with Bostik Seal'N'Flex FC or Wurth KD Bond and seal, and use suitable foamback tape to ensure sign stays in position while the adhesive is curing.

