

Maintenance Procedure for Ecoglo Products

Planned preventative maintenance and responsive maintenance should be carried out to ensure the following:

- All products are still configured as at installation and there is no material damage to any of these products.
- All products are clean from general dust build up and any other specific obscuring deposits.
- All products are clearly visible and have not been covered up by carpet, wallpaper, paint or other materials.
- All products mark a clear path and have not been obstructed by physical hazards (furniture, trolleys, partitions, machinery, vehicles, products, storage, racking, etc).
- All products can be used to provide clear escape path marking and there has been no change to the configuration of the building which renders the escape path unusable.
- All Ecoglo Hybrid signs are still illuminated.
- All lights within 4m of internal Ecoglo S20- exit signs, steps, ramps, and Ecoglo-marked paths and doorways have been checked that the positions have not altered from design.
- All lights within 4m of internal Ecoglo S20- exit signs, steps, ramps, and Ecoglo-marked paths and doorways are in working order and clean.
- All light switching controls are operational as per the design.

Please note: Photoluminescent exit signs and escape path markings should be replaced after 15 years when installed outdoors, or replaced after 30 years when installed indoors, unless evidence is provided to show ongoing compliance.

For specific information relating to periodic inspection and maintenance procedures for photoluminescent exit signs and path markings, refer to the Photoluminescent Lighting Council Standard PLCS 102(NZ) Passive Photoluminescent Exit Signs and Path Markings: Inspection and Maintenance available for download from www.ecoglo.co.nz.

For Ecoglo Hybrid signs refer to the Photoluminescent Lighting Council Standard PLCS 102H(NZ) Hybrid Photoluminescent Exit Signage: Inspection and Maintenance available for download from www.ecoglo.co.nz.